


CD-Player




DVD Player to TV 1




DVD Player to TV 2





How to use the REPLAY at the DVD Player !



Press Display
2x



Press Down Button
3x



Press Left Button



Chose Disk
And press Enter



Press Display ready